

Underground Geophysical Practical Course

Spectral Induced Polarization

Thomas Günther

thomas.guenther@geophysik.tu-freiberg.de

Jana Börner

jana.boerner@geo.uni-koeln.de







TUBAF

Die Ressourcenuniversität.
Seit 1765.









Induced Polarization (IP)

- increasing importance of ore deposits for raw material
- ore minerals (e.g. sulphides or oxides) often conductors
 - \Rightarrow exploration with electromagnetic methods
- Schlumbergers (1930) & Dachnov (1941) observed chargeability
- Method of Induced Polarisation (Bleil, 1953)
 - traditional ore exploration with induced polarization
- conductivity & polarization mechanisms of ores largely unknown
- extracting probes and measuring cells hard \Rightarrow in-situ


DC Equivalent (Dentith&Mudge, 2014)



AC Equivalent (Dentith&Mudge, 2014)




Time domain




Dentith & Mudge (2014)

Frequency domain




Phase shift



Dentith & Mudge (2014)


$$\sigma^* = \sigma' + i\sigma'' = |\sigma|e^{i\phi}$$

Membrane Polarisation




Dentith & Mudge (2014)

Polarisation



Relaxations



Debye relaxation

- fundamental polarisation

$$\sigma(\omega) = \sigma_{\infty} + (\sigma_0 - \sigma_{\infty}) \frac{m}{i\omega\tau}$$

- exponential decay

$$U(t) = U_0 m e^{-t/\tau}$$

Loewer et al. (2017)

Debye and Cole-Cole models

superposition of multiple decays

$$\rho^*(\omega) = \rho_0 \left(1 - \sum_{k=1}^K m_k \left(1 - \frac{1}{1 + i\omega\tau_k} \right) \right)$$

relaxation width: Cole-Cole

$$\rho^*(\omega) = \rho^0 \left[1 - m \left(1 - \frac{1}{1 + (i\omega\tau)^c} \right) \right]$$

Kramers-Kronig relations

Connect real und imaginary part of analytic functions

$$\rho''(\omega) = \frac{2\omega}{\pi} \int_0^{\infty} \frac{\rho'(x) - \rho'(\omega)}{x^2 - \omega^2} dx$$

$$\rho'(\omega) = \rho'(\infty) + \frac{2}{\pi} \int_0^{\infty} \frac{x\rho''(x) - \omega\rho''(\omega)}{x^2 - \omega^2} dx$$

Measurement: SIP device





Plate electrodes (Rücker & Günther, 2011)



- Wenner array (AMNB)
- constant spacing a
- geometric factor $k = 4\pi a$
- EKG electrodes
- point vs. plate electrodes
- deformed potential & current
- slightly changed sensitivity

SIP measurement

Configuration

← 11.44 mHz

301.000 Ω

20.0 V

Min. Freq.

Shunt Resistor

Max. PA Voltage

☒ Filter (50Hz)
☐ Filter (60Hz)
☒ Drift Filter
☒ Robust Analysis
☒ Consider Cal. F.
☒ Dec. Frequency
☐ Save Time Series
☒ $U = Z \cdot I$

1.00

robuste Datenanalyse

3 ComPort

mrad Unit

☐ Simulation

	Address	Gain	Ref?
RU0	500	1	
RU1	501	1	-
RU2	-1	1	-
RU3	-1	1	-
RU4	-1	1	-
RU5	-1	1	-
RU6	-1	1	-
RU7	-1	1	-
RU8	-1	1	-
RU9	-1	1	-

Data-File

File Comment


Spectral Induced Polarization

LOAD Cable Layout


EXIT^{END}

kleinste gemessene Frequenz

SIP measurement



SIP measurement



Data analysis

Python

- make use of `pyGIMLi` package
- `conda create -n pg -c gimli -c conda-forge` or
- `pip install pygimli`
- make use of class `SIPspectrum`


Data analysis: raw data

```
1 spec = SIPSpectrum("example.res", k=k)
2 print(spec)
3 spec.showData()
```

SIPSpectrum object


nf=60 min/max=0.002512/45000.0

```
(<Figure size 640x480 with 2 Axes>,
 array([<Axes: title={'center': 'Py6p_grobA'},
        xlabel='f (Hz)', ylabel='$\\rho$
        ($\\Omega$ m)'>,
        <Axes: xlabel='f (Hz)', ylabel='$-\\phi$
        (mrad)'>], dtype=object))
```



Data analysis: check Kramers-Kronig


```
1 spec = SIPSpectrum("example.res")
2 fig, ax = spec.showDataKK()
3 fig.savefig("corrKK.svg")
```



Data analysis: coupling removal


```
1 spec = SIPSpectrum("example.res")
2 spec.removeEpsilonEffect()
3 fig, ax = spec.showDataKK()
```

- reliable data: $f=100\text{mHz}-1\text{kHz}$





Data analysis: filter

```
1 spec = SIPSpectrum("example.res")
2 spec.removeEpsilonEffect()
3 fig, ax = spec.showDataKK()
4 spec.cutF(1000.0)
5 spec.cutF(0.1, down=True)
6 fig, ax = spec.showData()
```




Data analysis: fit Cole-Cole

```
1 spec = SIPSpectrum("example.res")
2 spec.removeEpsilonEffect()
3 fig, ax = spec.showDataKK()
4 spec.cutF(1000.0)
5 spec.cutF(0.1, down=True)
6 spec.fitColeCole()
7 fig, ax = spec.showAll()
```



Data analysis: Debye decomposition

```
1 spec = SIPSpectrum("example.res")
2 spec.removeEpsilonEffect()
3 fig, ax = spec.showDataKK()
4 spec.cutF(1000.0)
5 spec.cutF(0.1, down=True)
6 spec.fitColeCole()
7 spec.fitDebyeModel()
8 fig, ax = spec.showAll()
```



Report

1. Compute geometric factor for used array
2. Load the data and plot them using SIPSpectrum
3. Process (check KK, filter) the data
4. Fit Cole & Debye models
5. Repeat for all measured rock types
6. Interpret the results
7. Discuss possible error sources
8. Evaluate applicability of the method & improvements

Further reading

- Course material [DC resistivity & Electromagnetics methods](#) (in German), including induced polarization
- Dentith M and Mudge ST (2014): Geophysics for the mineral exploration geoscientist. Cambridge University Press
- [pyGIMLi website](#), specifically examples on IP
- Rücker, C. & Günther, T. (2011): The simulation of Finite ERT electrodes using the complete electrode model. Geophysics 76(4), F227-238, [doi:10.1190/1.3581356](#).